

Firstly charge the Blushield Portable using the USB cable. Insert the small end of the USB cable into the slot and the large end into a USB socket on your computer or any phone charger sporting a USB socket. Push the ON/OFF button once to see the LED charging lights light up. One LED will be flashing. This indicates the charging level. Once fully charged the LEDs will no longer flash and four LEDs will be lit. This indicates that the portable is fully charged.

Push and hold the ON/OFF button for 2 seconds. The indicator LED will start flashing and then turn off. This is the normal function as this will flash every half minute or so. Wait 20 seconds and the LED will flash again and so on.

When the ON/OFF switch is held for 2 seconds it will power on the device and you will see an ascending of the LEDs indicating the powering on and in the ON mode. Pressing and holding the ON/OFF switch again for another 2 seconds will power off the device and you will see a descending of the LEDs indicating the powering off and in the OFF mode.

When in the OFF mode you will no longer see the LED flash indicator LED. This means the device is OFF. When in the ON mode you will see the LED flash indicator LED. This means the device is ON. The Blushield Portable carries a warranty for a period of 1 year. This covers factory defects or faults. This does not cover misuse, modification or neglect (dropping) which can be indicated by scratched surfaces. If a claim is to be made all postage costs are to be covered by the customer. Blushield will decide whether to repair or replace product depending upon the fault.

It is not recommended to charge the portable for more than the required time. Once the indicator lights stop flashing the unit can be unplugged and used as required. A single charge will enable the portable to be used for about 5 days before needing to be recharged again. This product meets all safety standards and can be safely used on a plane or any aircraft with confidence. All safety certifications have been laser engraved on the back of every portable.

This product is not water proof but will withstand minimal water splashes, as long as the water does not enter the USB charging port, or the power button. If water does enter the portable then power down the device and place in a container of rice or in a warm dry lace for a couple of days, before powering up again. The warranty does not cover water damage and if full submersion occurs it is more than likely to render the portable useless.